

# RCA G1 MOBILE PHONE USER MANUAL

## Content

1. General Information	3	4.3	Calendar	15
1.1 Profile	3	4.4	Camera and video	15
1.2 Safety Warning and Precautions	3	4.5	Clock	15
2. Your phone	7	4.6	Contacts	15
2.1 Phone Layout	7	4.7	Send a Text Message	15
2.2 Functions of Keys	7	4.8	Downloads	16
2.3 Status bar	8	4.9	Email	16
3. Getting started	8	4.10	File Manager	16
3.1 Installing the Micro SIM Cards, SD card and the Battery	8	4.11	FM Radio	17
3.2 Charging the Battery	9	4.12	Gallery	17
3.3 Linking to the Networks and devices	10	4.13	Maps	17
3.4 Using the touch screen	12	4.14	Tethering and Portable hotspot	17
3.5 Using the screen keypad	12	4.15	Display	17
3.6 Make a Call	13	4.16	Security	18
3.7 Personal Data	13	4.17	SIM Toolkit	18
4. Using the Menus	14	4.18	Videos	19
4.1 Browser	14	4.19	Webcam	19
4.2 Calculator	14	5	Appendix	19

## 1. General Information

Please read and follow all instructions in this manual before using the device to ensure the longest lifespan of your device and battery.

The specifications and features are subject to change without notice, and the final right to interpret the performance of this mobile phone is reserved. Due to different software and network operators, display on your phone may be different, refer to your phone for details.

### 1.2 Safety Warning and Precautions

**SAFETY WARNING**

The Safety Information and Precautions in this manual must be followed to minimize the risk of fire or explosion, electric shock or to prevent property damage, personal injury, or death. If you notice strange smells or sounds coming from your device or the battery, or if you see smoke or liquids leaking from the device or battery, stop using the device immediately and contact RCA Customer Service. Failure to do so may result in fire or explosion.

**ROAD SAFETY COMES FIRST**

Do not use your mobile phone while driving, use hands-free fittings when the calls are unavoidable. In some countries, dialing or receiving calls while driving is prohibited by law.

**SWITCH OFF IN AIRCRAFT**

Wireless devices can cause interference in aircraft. While using your mobile phone is switched off during takeoff and landing. After take off, you can use the device in **Airplane Mode** if allowed by aircraft personnel.

**SWITCH OFF BEFORE ENTERING RISKY AREAS**

Strictly observe the relevant laws, codes, and regulations on the use of mobile phones in risky areas. Switch off your mobile phone before entering a place susceptible to explosion, such as an oil station, oil tank, chemical plant or a place where a blasting process is under way.

**OBSERVE ALL SPECIAL REGULATIONS**

Follow any special regulations in force in any area such as hospitals and always switch off your phone in fire or explosion.

whenever it is forbidden to use it or, when it may cause interference or danger. Properly use your mobile phone near medical apparatuses, such as pacemakers, hearing aids and some other electronic medical devices, as it may cause interference to such apparatuses.

**INTERFERENCE**

The conversation quality of any mobile phone may be affected by radio interference. An antenna is built inside the mobile phone and located below the microphone. Do not touch the antenna area during a conversation, otherwise the call quality will be deteriorated.

**MALWARE AND VIRUSES**

To protect your device from malware and viruses, do not download unknown applications or visit untrusted websites, delete suspicious messages or email from unknown senders.

Use the battery only for their intended purposes. Disconnect the charger from power sources when not in use.

Do not disassemble or puncture the battery, as this can cause explosion or fire.

Turn off the device before removing the battery. If you remove the battery with the device turned on, it may cause damage to the device.

Only RCA approved personnel may install or repair phone equipment. Installing, disassembling, modifying or repairing the mobile phone on your own may bring great danger and void your manufacturer's warranty. If your device needs servicing, contact RCA Customer Service.

**ACCESSORIES**

Use only approved accessories and batteries. RCA cannot be responsible for the user's safety when using accessories that are not approved by RCA.

**BATTERY SAFETY**

**CAUTION:** Use only RCA-approved chargers, batteries, and cables. Unapproved chargers or cables can cause the battery to explode or damage the device.

If the battery terminals come into contact with metal objects, this may cause a fire.

Use the battery only for their intended purposes. Disconnect the charger from power sources when not in use.

Do not disassemble or puncture the battery, as this can cause explosion or fire.

Turn off the device before removing the battery. If you remove the battery with the device turned on, it may cause damage to the device.

may cause the device to malfunction.

- Do not touch gold-colored contacts or terminals with your fingers or metal objects. If dirty, clean the battery terminals with a cotton ball or a towel.
- Do not dispose of the battery or device in a fire.
- Do not use a damaged charger or battery.
- Do not place the battery or device near or in heating devices, such as heaters, microwaves, stoves, hot cooking equipment, or high pressure containers or radiators.
- The device may explode when overheated.
- Follow all local regulations when disposing of used battery or device.

**EMERGENCY CALLS**

Ensure the phone is switched on and in service, enter the emergency number, for example 911, then press the Dial key. *Note: Just like all other mobile phones, this mobile phone does not necessarily support all the features described in this manual due to network or radio transmission problems. Some networks even do not support the emergency call service. And emergency calls from your device may not be possible in some areas or circumstances. Therefore, do not rely solely on the mobile phone for critical communications such as first aid. Please consult the local network operator.*

**PRECAUTIONS**

- Keep the mobile phone and all its fittings as SIM cards beyond children's reach.
- Keep the mobile phone dry. Keep away from rain, moisture, liquid or other substances that may damage and corrode electronic circuits.
- Do not use or store the mobile phone in dusty places, which leads parts of the mobile phone to be damaged.
- Do not use your device while it is charging or touch any device with wet hands.
- Do not touch the power cord with wet hands or disconnect the charger by pulling the cord.
- Do not turn on your device if it is wet. If your device is already on, turn it off immediately.
- Do not bend or damage the power cord.
- Do not short-circuit the charger or the device.
- Do not use your device outdoors during a thunderstorm.
- Do not expose your device to direct sunlight for extended periods of time (like on the dashboard of a car).
- Do not store your device in very hot areas such as inside a car in the summertime. Doing so may cause the screen to malfunction, result in damage to the device, or cause the battery to explode. High temperature will also shorten the life of electronic circuits and damage the battery and some plastic parts.
- Do not store the mobile phone in a chilly place. Otherwise, moisture will be formed inside the mobile phone to damage electronic circuits when the mobile phone is moved to a constant temperature place.
- Do not use your device with the back cover removed. The battery may fall out of the device, which may result in damage or malfunction.
- Do not throw, knock or shock the mobile phone, as that will destroy the internal circuits and high-precision components of the mobile phone.
- Do not store your device near magnetic fields. Your device may malfunction or the battery may discharge from exposure to magnetic fields.
- Do not use a camera flash or light close to the eyes of people or pets.
- Do not use a headset while driving or riding. Doing so may distract your attention and cause an accident, or may be illegal depending on your region.

to malfunction, result in damage to the device, or cause the battery to explode. High temperature will also shorten the life of electronic circuits and damage the battery and some plastic parts.

Do not store the mobile phone in a chilly place. Otherwise, moisture will be formed inside the mobile phone to damage electronic circuits when the mobile phone is moved to a constant temperature place.

Do not use your device with the back cover removed. The battery may fall out of the device, which may result in damage or malfunction.

Do not throw, knock or shock the mobile phone, as that will destroy the internal circuits and high-precision components of the mobile phone.

Do not store your device near magnetic fields. Your device may malfunction or the battery may discharge from exposure to magnetic fields.

Do not use a camera flash or light close to the eyes of people or pets.

Do not use a headset while driving or riding. Doing so may distract your attention and cause an accident, or may be illegal depending on your region.

Do not expose the device to heavy smoke or fumes.

Do not expose the device to high external pressure, which can lead to an internal short circuit and overheating.

Do not expose to loud sounds while walking may distract your attention and cause an accident.

Do not use headsets in dry environments or touch metal object to discharge static electricity before connecting a headset to the device.

Do not turn the volume up before plugging the earphones into an audio source and use only the proper volume setting near your conversation or music.

## 2. Your phone

### 2.1 Phone Layout

Device layout

### 2.2 Functions of Keys

- Power key**  
Power key is located on the top of the right edge of the phone. While using the phone, you can press this key to lock screen; if you press and hold this key, an option interface would pop out. Here, you can select to reboot, take screenshots or power off.
- Volume Key**  
Volume keys are on the left side of the phone. You can press them to adjust ringer, earpiece or media volume. You are also presented three options of None, Priority and All. When Priority mode is turned on, only a certain set of notifications are allowed to fire through to disturb you. You can control what falls into the Priority category, and what is left silent through the Interruptions section in Settings. Just remember to turn it back to All when your meeting, nap or movie is done. *Note:* None option of the Priority notification settings also turns off the alarm.
- Menu Key**

Touch this icon to access options of a selected function;

- Home Key**  
Touch it to open home screen. If you're viewing the left or right extended Home screen, touch it can enter the central screen.
- Back Key**  
Touch this icon to return to the previous screen;

### 2.3 Status bar

Icon	Description
	Airplane mode is switched on.
	Bluetooth is switched on.
	Wi-Fi is connected.
	Phone is connected to PC via USB connector.
	GPS is in use.
	Call is in progress.
	Call is on hold.
	SIM card is full.
	Keyboard is in use.
	Signal strength.
	Battery is charging.
	New text message.
	New email.
	Alarm.
	Event notification.
	Missed call.

Touch this icon to return to the previous screen;

Touch this icon to return to the previous screen;

Touch this icon to return to the previous screen;

### 3. Getting started

#### 3.1 Installing the Micro SIM Cards, SD card and the Battery

Insert the SIM card(s) provided by the GSM mobile phone service provider. *Note: After powering off your mobile phone, wait for a few seconds before removing or inserting a SIM card. Exercise caution when operating a SIM card, as friction or bending will damage the SIM card. Properly keep the mobile phone and its fittings such as the SIM cards beyond children's reach.*

**Installation**

- Power off the mobile phone.
- Take the back cover away.
- Carefully insert the SIM card into the SIM card slot, with the logo facing up, until the card locks into place. *When inserting a card, make sure the angled corner of the card is positioned correctly. If the SIM card is not inserted correctly, the device will not detect it.*
- Do not remove a card while the device is transferring or accessing information, as this could result in loss of data and/or damage to the card or device.
- Protect cards from strong shocks, static electricity, and electrical noise from other devices.
- Note: The SD card is a miniature object. Keep it out of the reach of children for fear that children swallow it!*

#### 3.2 Charging the Battery

your mobile phone can monitor and display the battery charge status.

- When connecting a cable to your device, make sure that the cable is connected to the proper side.
- The remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- When the battery energy is insufficient, the mobile phone prompts "Battery low".
- Install the battery into the mobile phone before charging the battery.
- Over time, unused device will discharge and must be recharged before use.
- Insert the plug of the charger into an appropriate power outlet.
- During the charging, the battery level grids in the battery icon will flicker until the battery is fully charged.
- Turn down screen brightness and set a shorter screen timeout.
- If you don't need them, turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Note: On the Home screen, press Menu icon and tap Settings > Battery. The Battery Use screen lists the applications that have been using the battery, from greatest to least battery use. The top of the screen displays the remaining time before you need to connect to a charger. Then each application or service that used power during that time is displayed, in order of the amount of power they used. Touch an application in the Battery Use screen to learn details about its power consumption. Different applications offer different kinds of information.*

friction or bending will damage the SIM card. Properly keep the mobile phone and its fittings such as the SIM cards beyond children's reach.

**Installation**

- Power off the mobile phone.
- Take the back cover away.
- Carefully insert the SIM card into the SIM card slot, with the logo facing up, until the card locks into place. *When inserting a card, make sure the angled corner of the card is positioned correctly. If the SIM card is not inserted correctly, the device will not detect it.*
- Do not remove a card while the device is transferring or accessing information, as this could result in loss of data and/or damage to the card or device.
- Protect cards from strong shocks, static electricity, and electrical noise from other devices.
- Note: The SD card is a miniature object. Keep it out of the reach of children for fear that children swallow it!*

### 3.2 Charging the Battery

your mobile phone can monitor and display the battery charge status.

- When connecting a cable to your device, make sure that the cable is connected to the proper side.
- The remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- When the battery energy is insufficient, the mobile phone prompts "Battery low".
- Install the battery into the mobile phone before charging the battery.
- Over time, unused device will discharge and must be recharged before use.
- Insert the plug of the charger into an appropriate power outlet.
- During the charging, the battery level grids in the battery icon will flicker until the battery is fully charged.
- Turn down screen brightness and set a shorter screen timeout.
- If you don't need them, turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Note: On the Home screen, press Menu icon and tap Settings > Battery. The Battery Use screen lists the applications that have been using the battery, from greatest to least battery use. The top of the screen displays the remaining time before you need to connect to a charger. Then each application or service that used power during that time is displayed, in order of the amount of power they used. Touch an application in the Battery Use screen to learn details about its power consumption. Different applications offer different kinds of information.*

Optimizing Battery Life

You can extend your battery's life between charges by turning off features that you don't need and turning on Battery Saver and Standby Intelligent Power Saving. You can also check how applications and system resources consume battery power. To guarantee the optimal performance of your battery, please stick to the following rules:

- Turn off radios that you aren't using. If you aren't using Wi-Fi, Bluetooth, or GPS, turn them off.
- Turn down screen brightness and set a shorter screen timeout.
- If you don't need them, turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Note: On the Home screen, press Menu icon and tap Settings > Battery. The Battery Use screen lists the applications that have been using the battery, from greatest to least battery use. The top of the screen displays the remaining time before you need to connect to a charger. Then each application or service that used power during that time is displayed, in order of the amount of power they used. Touch an application in the Battery Use screen to learn details about its power consumption. Different applications offer different kinds of information.*

Optimizing Battery Life

You can extend your battery's life between charges by turning off features that you don't need and turning on Battery Saver and Standby Intelligent Power Saving. You can also check how applications and system resources consume battery power. To guarantee the optimal performance of your battery, please stick to the following rules:

- Turn off radios that you aren't using. If you aren't using Wi-Fi, Bluetooth, or GPS, turn them off.
- Turn down screen brightness and set a shorter screen timeout.
- If you don't need them, turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Note: On the Home screen, press Menu icon and tap Settings > Battery. The Battery Use screen lists the applications that have been using the battery, from greatest to least battery use. The top of the screen displays the remaining time before you need to connect to a charger. Then each application or service that used power during that time is displayed, in order of the amount of power they used. Touch an application in the Battery Use screen to learn details about its power consumption. Different applications offer different kinds of information.*

### 3.3 Linking to the Networks and devices

Your phone can connect to a variety of networks and devices, including mobile networks for voice and data transmission, Wi-Fi data networks, and Bluetooth devices, such as headsets. You can also connect your phone to a computer, to transfer files from your phone's storage or SD card and share your phone's mobile data connection via USB cable or Bluetooth.

**Connecting to mobile networks**

When you assemble your phone with a SIM card, your phone is configured to use your provider's mobile networks for voice calls and for transmitting data.

When a SIM card is enabled, you can:

- Set SIM card name, turn on or turn off the SIM card.
- Set preferred SIM slot for voice call, data call and SMS.

**Setting up cellular data**

- Tap the "Apps" icon located in the center bottom section of the screen
- Go to the main menu, and look for **Settings**
- Tap on "Data usage"
- Tap on the name of the mobile phone carrier and then tap the empty check box to the right of "Cellular data". This will

put a blue check in the "Cellular data". When the cellular data is enabled, if the "H" or "E" is not displayed on the top of the screen or you sign up with a Mobile Virtual Network Operator (MVNO), which network operates on big carriers, you might need to configure your phone's APN settings. The APN Settings are a unique combination of values, please contact your carrier for the newest APN as this differ from network operator to network operator. To get started configuring APN settings:

- Go to the main menu, and look for **Settings**
- Tap on **More**
- Go into where it says **Cellular Networks**
- Tap on **Access Point Names**
- You should see the PLUS icon to **ADD NEW**

**Data Roaming:** Look for **Settings**, tap **SM Management**, and then tap the empty check box to the right of "Roaming". Read the attention and click "OK". This will put a blue check in the "Data Roaming" box. Data roaming should now be active. *Note: additional*

charges may apply when using roaming service, check the rates with your carrier.

**Virtual Private Network:** Look for **Settings**, tap **More**, and then tap "VPN", then you can configure connections between your phone and virtual private networks (VPNs).

**Connecting to Wi-Fi networks**

Wi-Fi can provide Internet access at distances which depend on the Wi-Fi router and your surroundings. Go to the main menu, and look for **Settings**, tap "Wi-Fi", then tap the empty check box to the right of "On". The phone will scan for available Wi-Fi networks and displays the names it finds. Secured networks are indicated with a Lock icon. *Note: If the phone finds a network that you connected to previously, it may connect to it automatically.* Touch a network to connect to it. If the network is open, you are prompted to confirm that you want to connect to that network by touching Connect. If the network is secured, you're prompted to enter a password or other credentials.

**Connecting to Bluetooth devices**

Bluetooth is short-range wireless communications that makes it possible to exchange information over a short distance. The most common Bluetooth devices are headphones for making calls or listening to music, hands-free kits for cars, and other portable devices, including laptops and cell phones. Go to the

main menu, and look for **Settings**, tap "Bluetooth", then tap the empty check box to the right of "On". You must pair your phone with a device before you can connect to it. Once you pair your phone with a device, they stay paired unless you unpair them. Your phone scans for and displays the IDs of all available Bluetooth devices in range. If the device you want to pair with isn't in the list, make it discoverable.

**Connecting to a computer via USB**

You can connect your phone to a computer with a USB cable, to transfer music, pictures, and other files between your phone's SD card and the computer.

### 3.4 Using the touch screen

- Touch-screen tips**
- Tap**  
To activate items on the screen, such as application and settings icons, to type text and symbols using the onscreen keyboard, you may simply tap them with your finger.
- Touch & hold**  
Touch & hold an item on the screen by touching and not lifting your finger until an action occurs. For example, to open a menu for customizing the Home screen, you touch an empty area until the menu opens.
- Drag**

Touch & hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position.

- Swipe or slide**  
To swipe or slide, you quickly move your finger across the surface of the screen, without pausing when you first touch it (so you don't drag an item instead). For example, you slide the screen up or down to scroll a list.
- Lock screen**  
When the Screen lock is enabled in Security setting, press Power key located on the top of the right edge of the phone. When Sleep is enabled in Display Settings, the screen will be locked automatically to save power.
- Unlock screen**  
Press the power key and then unlock your phone by dragging the padlock symbol to the right.
- Using the on screen keypad**
- To enter text**  
Touch a textfield, and the on screen keyboard will open. Some applications open the keyboard automatically. Choose which languages are available on the keyboard. To switch between languages, touch the space bar.
- Use the Delete icon and Back icon.**  
Use the Delete icon to erase characters. Touch Back icon to close the keyboard.

- Select your default keyboard or input method  
From a Home screen, tap Settings > Language and input > Android Keyboard settings > Select a keyboard. *Note: Additional keyboards can be downloaded from the Google Play Store.*
- Make a Call**
- Dial a number from keypad**
- Tap the PHONE icon in the bottom left of the screen
- Tap the number pad icon at the bottom of the screen
- The number pad will then appear. Input the phone number you wish to dial and then tap the telephone icon to make the call.
- Dial a number from Contact List**
- Tap PHONE CONTACTS or tap APPS CONTACTS from a Home Screen.
- Alternatively, you can tap the search icon at the top, type the contact you wish to call, then tap the phone number that appears to call the contact.
- Dial a Recent Number**  
All incoming, outgoing, and missed calls are recorded in the Call log. If the number or caller is listed in your contacts list, the associated name is also displayed.
- Tap PHONE icon**
- Tap RECENTS** A list of recent calls is displayed.
- Tap a contact**, and then tap **Call**.

- Answering incoming calls**
- Drag the Answer icon towards right to answer an incoming call.
- Touch the End icon to end the current conversation.
- To reject an incoming call, drag the End icon towards left.
- Managing multiple calls**
- Accept a new call when you're already on a call, you can drag the Answer icon towards right.
- Personal Data**  
Protect your personal data and prevent leakage or misuse of sensitive information
- While using your device, be sure to back up important data. RCA is not responsible for the loss of data.
- When disposing of your device, back up all data and then reset your device to prevent misuse of your personal information.
- Carefully read the permissions screen when downloading applications. Be particularly cautious with applications that have access to many functions or to a significant amount of your personal information.
- Check your accounts regularly for unapproved or suspicious apps.
- Choose whether you want to save the contact to the application, contact your service provider to delete or change your account information.
- In the event your device is lost or stolen, change the

passwords on your accounts to protect your personal information.

- Avoid using passwords from unknown sources and lock your phone with a pattern, password or PIN.

### 4. Using the Menus

#### 4.1 Browser

You can use Browser to view web pages and search for information on the web.

- To go to a webpage or search the web**  
Touch the URL box at the top of the browser screen. Enter the address (URL) of a webpage. Or enter terms you want to search for. As you enter text, your web search engine makes suggestions of web pages and queries.
- To refresh the current page**  
Touch Menu icon and an option interface appears, then you can tap Refresh to update the current web page.
- To zoom in or out on a webpage**  
Slide your finger slightly left or right to reveal the Zoom control. Touch the plus or minus side of the Zoom control to zoom in or out.
- To find text on a webpage**  
Touch Menu icon and tap "Find on page". Enter the text you're looking for. As you type, the first text with matching characters is highlighted on the screen, and subsequent matches are boxed. Touch the up or down arrow to scroll to and highlight the previous or next matching word.

- Copy text from webpage**  
Use your finger to long press the text you want to copy. It will pop up some options, select the **Select text** option to select the text you want, and then tap the icon at the right top corner of the screen to copy or share the text.
- Unlink screen**  
Press the power key and then unlock your phone by dragging the padlock symbol to the right.
- Using the on screen keypad**
- To enter text**  
Touch a textfield, and the on screen keyboard will open. Some applications open the keyboard automatically. Choose which languages are available on the keyboard. To switch between languages, touch the space bar.
- Use the Delete icon and Back icon.**  
Use the Delete icon to erase characters. Touch Back icon to close the keyboard.

### 4.3 Calendar

- Creating an event**  
Tap CALENDAR from a Home screen > touch Menu Key > enter details for the event > tap Done to save.
- Delete an Event**  
When the CALENDAR is opened, tap DELETE icon at upper right corner.
- Share an Event**  
Tap SHARE icon and then choose a sharing format.
- Synchronizing and displaying calendar**  
When you add a Google Account or Microsoft Exchange ActiveSync account in the Calendar Settings, you can configure the accounts to synchronize calendar events to the phone, and the events from the calendar will be displayed on the phone.
- Change Calendar settings**  
Open a CALENDAR view, tap menu icon and then select settings.

#### 4.4 Camera and video

Touch the Camera icon from a home screen, compose the shot by aiming the camera at the subject. If desired, before taking the photo, you can touch onscreen icons to access various camera options and settings. You can also touch the screen to move the focus field to the area you touch. Tap Capture to take the picture. You can tap the video icon to start recording or touch menu icon to pop out an option box for switching.

### 4.5 Clock

Tap the Clock icon from a Home screen. You can use Alarm, World Clock, Stopwatch and Timer functions.

**Alarm:** This feature allows you to set an alarm to ring at a specified time.

**World Clock:** View the time in other parts of the world at a specified time.

**Stopwatch:** Measure intervals of time.

**Timer:** Use a timer to count down to an event based on a preset time length (hours, minutes, and seconds).

### 4.6 Contacts

- Tap the CONTACTS icon from a Home screen
- Tap the add new contact icon at the bottom of the screen
- Choose whether you want to save the contact to the Google account, the SIM card or the phone
- Fill in all the contact information and when completed, tap "Done" at the top of the screen

### 4.7 Send a Text Message

- Tap the MESSAGING icon in the bottom of the screen
- Tap the add new message icon in the bottom left hand corner of the screen
- Type in the phone number or the name of the person you are sending the message to
- When you have completed your message, tap the send message icon to send the message

### 4.8 Downloads

Tap DOWNLOADS icon, you can view a list of files and applications which you downloaded from the webpage.

### 4.9 Email

You can use the Email application to read and send email. Touch Email icon when you have an email account in a few steps.

- Account setup**  
Enter an Email address and the account's password.
- Account settings**  
Set in box checking frequency.
- Set Send email from this account by default.
- Set whether you want to save the contact to the Google account, the SIM card or the phone
- Set Automatically download attachments when connected to Wi-Fi.
- Compose and sending Email**  
To compose and send an Email:  
1. Touch the create icon to compose a new Email.  
2. Enter Email addresses (or intended recipient(s)).  
3. Touch Menu -> Attach file to attach a file.  
4. Touch Menu -> Attach Cc/Bcc to add copy or blind copy this Email to other contacts.  
5. After completing the Email, Touch send icon to send the Email. Touch folder icon to check the account status.

For each Email account, there are five default folders, i.e., Inbox, Drafts, Outbox, Send and Trash folders. To view sent Emails, open Sent folder and tap refresh icon.

- Adding and editing Email accounts**
- Add an Email account**
  - Open Email application.
  - Touch Menu to enter Settings interface.
  - Touch ADD ACCOUNT on top-right of the display.
- Change account settings**
  - Enter Settings interface and touch General to view general settings for all accounts.
  - Enter Settings interface and touch the account to view the account settings.
- Delete an Email account**
  - Enter Settings interface.
  - Touch the account to delete.
  - In account settings interface, touch Remove account to delete this account.

#### 4.10 File Manager

You can use the File Manager to access and manage various files including images, videos, songs, ringtones, downloads, applications files on the Phone Storage and SD card.

friction or bending will damage the SIM card. Properly keep the mobile phone and its fittings such as the SIM cards beyond children's reach.

**Installation**

- Power off the mobile phone.
- Take the back cover away.
- Carefully insert the SIM card into the SIM card slot, with the logo facing up, until the card locks into place. *When inserting a card, make sure the angled corner of the card is positioned correctly. If the SIM card is not inserted correctly, the device will not detect it.*
- Do not remove a card while the device is transferring or accessing information, as this could result in loss of data and/or damage to the card or device.
- Protect cards from strong shocks, static electricity, and electrical noise from other devices.
- Note: The SD card is a miniature object. Keep it out of the reach of children for fear that children swallow it!*

### 3.2 Charging the Battery

your mobile phone can monitor and display the battery charge status.

- When connecting a cable to your device, make sure that the cable is connected to the proper side.
- The remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- When the battery energy is insufficient, the mobile phone prompts "Battery low".
- Install the battery into the mobile phone before charging the battery.
- Over time, unused device will discharge and must be recharged before use.
- Insert the plug of the charger into an appropriate power outlet.
- During the charging, the battery level grids in the battery icon will flicker until the battery is fully charged.
- Turn down screen brightness and set a shorter screen timeout.
- If you don't need them, turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Note: On the Home screen, press Menu icon and tap Settings > Battery. The Battery Use screen lists the applications that have been using the battery, from greatest to least battery use. The top of the screen displays the remaining time before you need to connect to a charger. Then each application or service that used power during that time is displayed, in order of the amount of power they used. Touch an application in the Battery Use screen to learn details about its power consumption. Different applications offer different kinds of information.*

Optimizing Battery Life

You can extend your battery's life between charges by turning off features that you don't need and turning on Battery Saver and Standby Intelligent Power Saving. You can also check how applications and system resources consume battery power. To guarantee the optimal performance of your battery, please stick to the following rules:

- Turn off radios that you aren't using. If you aren't using Wi-Fi, Bluetooth, or GPS, turn them off.
- Turn down screen brightness and set a shorter screen timeout.
- If you don't need them, turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Note: On the Home screen, press Menu icon and tap Settings > Battery. The Battery Use screen lists the applications that have been using the battery, from greatest to least battery use. The top of the screen displays the remaining time before you need to connect to a charger. Then each application or service that used power during that time is displayed, in order of the amount of power they used. Touch an application in the Battery Use screen to learn details about its power consumption. Different applications offer different kinds of information.*

Optimizing Battery Life

You can extend your battery's life between charges by turning off features that you don't need and turning on Battery Saver and Standby Intelligent Power Saving. You can also check how applications and system resources consume battery power. To guarantee the optimal performance of your battery, please stick to the following rules:

- Turn off radios that you aren't using. If you aren't using Wi-Fi, Bluetooth, or GPS, turn them off.
- Turn down screen brightness and set a shorter screen timeout.
- If you don't need them, turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Note: On the Home screen, press Menu icon and tap Settings > Battery. The Battery Use screen lists the applications that have been using the battery, from greatest to least battery use. The top of the screen displays the remaining time before you need to connect to a charger. Then each application or service that used power during that time is displayed, in order of the amount of power they used. Touch an application in the Battery Use screen to learn details about its power consumption. Different applications offer different kinds of information.*

### 3.3 Linking to the Networks and devices

Your phone can connect to a variety of networks and devices, including mobile networks for voice and data transmission, Wi-Fi data networks, and Bluetooth devices, such as headsets. You can also connect your phone to a computer, to transfer files from your phone's storage or SD card and share your phone's mobile data connection via USB cable or Bluetooth.

**Connecting to mobile networks**

When you assemble your phone with a SIM card, your phone is configured to use your provider's mobile networks for voice calls and for transmitting data.

When a SIM card is enabled, you can:

- Set SIM card name, turn on or turn off the SIM card.
- Set preferred SIM slot for voice call, data call and SMS.

**Setting up cellular data**

- Tap the "Apps" icon located in the center bottom section of the screen
- Go to the main menu, and look for **Settings**
- Tap on "Data usage"
- Tap on the name of the mobile phone carrier and then tap the empty check box to the right of "Cellular data". This will

### 4.11 FM Radio

Plug in the